

EW1022 Eyewash/Drench Hose Unit, Deck Mounted **EW1022BP** Eyewash/Drench Hose Unit, Deck Mounted, with Backflow Preventer

Application: Dual purpose eyewash/drench hose for deck mounting. Unit meets the provisions of ANSI Z358.1-2014 as both an eyewash and a drench hose. Unit may be left in the deck flange for use as a fixed eyewash, leaving user's hands free. Alternatively, unit may be removed for use as a drench hose to rinse any part of user's eyes, face or body.

Spray Head Assembly: Two GS-Plus[™] spray heads mounted side-by-side. Each head has a "flip top" dust cover, internal flow control and filter to remove impurities from the water flow.

Valve: Forged brass squeeze valve activated by stainless steel lever handle. Valve has replaceable stainless steel seat for exceptional durability. Locking clip engages when handle is depressed, providing "hands free" operation. Valve stays open until locking clip is released.

Hose: 8' reinforced PVC hose. 275 PSI maximum working pressure.

Mounting: Deck flange for countertop mounting. Flange has handle locator guide to position spray heads and handle facing forward at all times.

Backflow Preventer: In-line dual check backflow preventer installed on inlet of hose (EW1022BP only). ASSE 1024 Listed. Note: Check with code authority for compliance with local plumbing code.

Supply: 3/8" NPT male swivel-type inlet.

Sign: ANSI-compliant identification sign.

Quality Assurance: Unit is completely assembled and water tested prior to shipment.

Available Options

FSH 8 ft. flexible stainless steel hose in place of PVC hose.

HG Undercounter hose guide bracket to prevent hose from tangling or binding.

VB In-line vacuum breaker for installation between valve and spray head.

AP3600 Thermostatic mixing valve precisely blends hot and cold water to deliver warm (tepid) water as required by ANSI Z358.1-2014. Refer to "Tempering Valves" section for complete technical and product selection information.







EW1022 Eyewash/Drench Hose Unit, Deck Mounted

EW1022BP Eyewash/Drench Hose Unit, Deck Mounted, with Backflow Preventer



WaterSaver Faucet Co.312 (701 W Erie St312 (Chicago, IL 60654wsfl

312 666 5500 TELEPHONE 312 666 5501 FACSIMILE wsflab.com Listed 8116. Units have been tested to and comply with ANSI Z358.1-2014 and the Uniform Plumbing Code.

